

CARDIO T916 TREADMILL

ITEM # 100152



FOR YOUR PROTECTION,  
THIS EQUIPMENT HAS  
BEEN TREATED WITH  
mPale™ ANTIMICROBIAL.

[www.mpactusa.com](http://www.mpactusa.com)

The Nautilus® T916 treadmills are so versatile, they work for everyone. They combine cutting-edge technology, superb craftsmanship, and heavy-duty materials with the backing of the Quinton® and Nautilus® brands. Ironically the Nautilus® T916 treadmill is also the simplest to use, getting users on the road to their workouts in no time at all.

The T916 uses our patented REACT® absorption control technology, which protects the user's ankles, knees, hips, and back by providing the most advanced and most dynamic cushioning system available. Some users will use our treadmill to walk, others to jog, and still others to run. Whatever their pace, their stride, or their incline, the REACT® system will adjust automatically, so the surface will never be too hard, and never too soft.

The third-generation 4.8 AC Hyperdrive system backed by Quinton delivers extraordinary torque to the belt, resulting in a longer lasting belt and deck, more accurate speed control and smooth, fluid motion.

- Most powerful treadmill on the planet- 600 pound capacity to 4 mph
- 63" bed length, 22" belt width
- .5-12 mph, 0-15% elevation
- No maintenance, triple-flex patented shock absorbing deck
- Ergo bar control pod for quick changes
- Heart rate sensors and wireless telemetry
- Extended rails standard
- Similar cardio console on all cardio units for ease of use
- Optional integrated LCD entertainment screens or Netpulse™
- 35" W x 88" L, Machine Weight: 370 lbs.
- Warranty: Frame/Motor: 15 years, Parts: 3 years, Wear items/Labor: 1 year