

CB900 Indoor Cycle



SPIRIT FITNESS

A Heritage of Quality | The Spirit of Innovation



CB900 Indoor Cycle

The **CB900** expounds on three critical areas – durability, comfort and performance. It is a perfect addition to a club, corporate fitness/recreation center, school or hotel because it's stout design will withstand hours of consistent use. The needle bearings that encompass the pedals and flywheel axle, industrial grade Hutchinson PK poly-V® belt, and our three piece crank work synergistically to create the perfect formula for durability and performance. The adjustments of the handlebars and seat in two directions along with SPD dual pedal design, and easy to maneuver "L" adjustment handles provide a comfortable fit for any size rider.

Other design elements include:

- Double Powder Coat paint process resists corrosion
- Cross Tube Model # decal prevents paint scratches
- Rear joint cover offers a convenient, efficient calf stretch
- Co-molded rotary knob for comfortable resistance adjustments
- Extra large diameter adjustable floor casters provide a stable base of support for heavier riders
- A concave groove on the inner edge of the flywheel perimeter disperses sweat to prevent corrosion

The premium ISIS bottom bracket cartridge features ten splines that ensure greater surface area contact, a sturdier connection, and less maintenance than a traditional square joint. This bottom bracket cartridge is used on high end bicycles. These attributes ensure top performance for the life of the product.



CB900 ISIS
Splined Spindle

CB900 Indoor Cycle



There are many key components responsible for optimum performance of an indoor cycle. The drive belt, pulley size and material, bottom bracket cartridge, gear ratio and three piece crank have been carefully chosen on the **CB900** to assure optimal performance and durability. These components, along with an ergonomically correct frame design and full fore/aft adjustability, combine to make the perfect indoor cycle for your facility.

Equipment Specifications

RESISTANCE	Rotary Knob; Micro-Adjustments
BRAKE	Felt Pad
DRIVE TRAIN	Industrial Grade Hutchinson PK PolyV® Belt
FLYWHEEL	Steel 44 lbs., Front
SEAT	Racing Saddle
FOOT PEDALS	Needle Bearings & O Ring Seals; SPD & Toe Cage
FRAME	Heavy Duty, 2.5mm Oval Steel Tubing; Double powder coated
HANDLEBAR/SEAT POSTS	Aluminum w/ stamped numerical height indicators
ADJUSTMENTS	Fore/Aft and Vertical Micro-adjustments of Handlebars/Seat
LEVERS	Easy to adjust "L" handles
DIMENSIONS	42" x 21" x 40.5"
PRODUCT WEIGHT	150 lbs.
MAX USER WEIGHT	350 lbs.

Warranty Information

COMMERCIAL WARRANTY (Dues Paying Facility)	10 Yrs: Frame
	3 Yrs: Parts
	1 Yr: Wear Items (Grips, End Caps, Calf Stretch Cover and Toe Cage Straps)
	1 Yr: Labor

COMMERCIAL WARRANTY (Non-Dues Paying Facility)	15 Yrs: Frame
	3 Yrs: Parts
	1 Yr: Wear Items (Grips, End Caps, Calf Stretch Cover and Toe Cage Straps)
	1 Yr: Labor



Smooth Felt Brake Pad

www.spiritfitness.com



3000 Nestle Road
Jonesboro, AR 72401
Phone: 800.258.4555
Fax: 870.935.7611