

CARDIO K2 VERTICAL CLIMBER

ITEM # K2-7 and K2-10



7" touch screen features iPod connectivity.



10.2" inch entertainment touch screen features iPod connectivity, charging and HDTV.



FOR YOUR PROTECTION, THIS EQUIPMENT HAS BEEN TREATED WITH mPale™ ANTIMICROBIAL.

www.mpactusa.com

The Nautilus K2 Vertical Climber features 20 levels of resistance, from 20-165 steps per minute accommodating nearly all fitness levels. V-Grip handles with integrated heart rate monitoring offer additional grip options, while our unique in the industry integrated cooling fan features HIGH, LOW and AUTO settings, with Auto adjusting the fan velocity as a function of exercise effort.

The K2's belt drive reduction system requires no lubrication (no chain or gear boxes), is smooth, quiet and reliable. Resistance mechanism and control boards are positioned in a separate compartment above the steps, assuring protection from perspiration and are easily accessible through the front hood. Stylized shielding provides a fresh and modern look.

Functions are operated from either a 7" touch or 10.2" entertainment touch screen. Back-up keypad can be used in case of touch screen failure. Web based software updates are available via standard memory stick. Both displays are multi-language capable, permit changing startup defaults, and feature built-in diagnostics. The 10.2" display adds iPod charging capability and integrated analog and digital TV.

- 10.2" LCD entertainment touch screen, built-in multimedia with iPod connectivity, charging and digital TV
- 7" touch screen features iPod connectivity
- Heart Rate: Wireless Integrated HR sensor, contact and wireless, with auto-select.
- Programs: Quick Start, Manual, Intervals, HR Zone and Interval, Fat Burner, Calorie, Calories Goal, Custom Interval, Random Play, Fitness Test, CPAT Test, and WFI Test Programs
- Step Tread: Tread depth of 9.5" (24.1 cm) Tread Width of 22" (55.9 cm)
- Step Action: Wide and Deep Step Staircase with 7.25" (18.4 cm) riser height Non-Slip surface
- First Step Height: 18" (45.7 cm) from grade level
- Integrated iPod connection and holder
- Easily accessible water bottle holder.
- Power Requirements: AC Adaptor 110/220 Volts required for advanced display options
- 31 1/4" W x 53" L x 80" H, Machine Weight: 400 lbs. Max user weight 400 lbs (182 kg)
- Warranty: Frame/Motor: 15years, Parts: 3years, Wear items/Labor: 1year

*Labor warranty not applicable to shipments outside the United States