

EVO COMPOUND ROW

ITEM # S9CR



FOR YOUR PROTECTION,
THIS EQUIPMENT HAS
BEEN TREATED WITH
mPale™ ANTIMICROBIAL.

www.mpactusa.com

Updated Look. Improved Function.

Nautilus Nitro® EVO features our patent pending 5 lb Increment weight stack, which is perfect for slight strength gains and ideal for newcomers, women and the elderly. Other features include:

- Updated Sleek, Partially Enclosed Weight Shields with a 5.5" Opening
- Marine Grade, Contoured Upholstery for Comfort & Durability
- Updated Exercise Placards for Ease of Use
- Integrated Parts Schematic Simplifies Service
- Proprietary Pin Design Limits Pilferage & Misuse Liability
- Enlarged Bottle Holder & Towel Knob for Convenience
- Multiple Color Options are Available for the Frame and Upholstery
- Warranty: 12 years- Frame/Welded Moving Parts/Weight Stacks, 3 years-Moving Parts, 1 year-Labor and 6 months on upholstery/pads/grips and tethered weight stack pins

It Moves the Way Your Body Moves. Driven by our four-bar linkage system, cam design or a combination of both, this unique technology dynamically matches the body's potential increases and decreases in strength. Users get immediate, smooth resistance and proper muscle loading through the complete range of motion, leading to unprecedented results.

COMPOUND ROW

The Nautilus Nitro® EVO Compound Row accommodates multiple movement paths with divergent and convergent movement- arm technology providing the user with a direct upper torso workout.

- Rotating Ergo Grip handles for natural and safe hand supination and pronation needs during movement
- Dependent movement arms allow for safe and user-defined planes of movement
- Function Generator four-bar linkage drive system to generate correct strength profile
- 75" L x 35" W x 67" H / 191 L x 89 W x 170 H cm
- Machine Weight: 527 lbs. / 239 kg, Weight Stack: 245 lbs. / 113 kg