

EVO LOWER BACK

ITEM # S9LB



FOR YOUR PROTECTION,
THIS EQUIPMENT HAS
BEEN TREATED WITH
mPale™ ANTIMICROBIAL.

www.mpactusa.com

Updated Look. Improved Function.

Nautilus Nitro® EVO features our patent pending 5 lb Increment weight stack, which is perfect for slight strength gains and ideal for newcomers, women and the elderly. Other features include:

- Updated Sleek, Partially Enclosed Weight Shields with a 5.5" Opening
- Marine Grade, Contoured Upholstery for Comfort & Durability
- Updated Exercise Placards for Ease of Use
- Integrated Parts Schematic Simplifies Service
- Proprietary Pin Design Limits Pilferage & Misuse Liability
- Enlarged Bottle Holder & Towel Knob for Convenience
- Multiple Color Options are Available for the Frame and Upholstery
- Warranty: 12 years- Frame/Welded Moving Parts/Weight Stacks, 3 years-Moving Parts, 1 year-Labor and 6 months on upholstery/pads/grips and tethered weight stack pins

It Moves the Way Your Body Moves. Driven by our four-bar linkage system, cam design or a combination of both, this unique technology dynamically matches the body's potential increases and decreases in strength. Users get immediate, smooth resistance and proper muscle loading through the complete range of motion, leading to unprecedented results.

LOWER BACK

The Nautilus Nitro® EVO Lower Back is the only full range, lumbar-isolated machine that emulates the function of rotation around multiple vertebrae.

- Four-bar linkage provides a moving axis of rotation that simulates the body's moving axis of rotation, increasing user safety by eliminating shear forces on the spine
- Large, flat back pad spreads out over larger area and pivots for user comfort
- Contoured lower back pad allows full range extension
- Adjustable foot platform to position knees above hip joint, eliminating pelvic thrust and maintaining axis alignment for a successful workout
- 56" L x 38" W x 54" H / 142 L x 97 W x 137 H cm
- Machine Weight: 572 lbs. / 259 kg, Weight Stack: 200 lbs. / 91 kg