

EVO LEG EXTENSION

ITEM # S9LE



FOR YOUR PROTECTION,
THIS EQUIPMENT HAS
BEEN TREATED WITH
mPale™ ANTIMICROBIAL.

www.mpactusa.com

Updated Look. Improved Function.

Nautilus Nitro® EVO features our patent pending 5 lb Increment weight stack, which is perfect for slight strength gains and ideal for newcomers, women and the elderly. Other features include:

- Updated Sleek, Partially Enclosed Weight Shields with a 5.5" Opening
- Marine Grade, Contoured Upholstery for Comfort & Durability
- Updated Exercise Placards for Ease of Use
- Integrated Parts Schematic Simplifies Service
- Proprietary Pin Design Limits Pilferage & Misuse Liability
- Enlarged Bottle Holder & Towel Knob for Convenience
- Multiple Color Options are Available for the Frame and Upholstery
- Warranty: 12 years- Frame/Welded Moving Parts/Weight Stacks, 3 years-Moving Parts, 1 year-Labor and 6 months on upholstery/pads/grips and tethered weight stack pins

It Moves the Way Your Body Moves. Driven by our four-bar linkage system, cam design or a combination of both, this unique technology dynamically matches the body's potential increases and decreases in strength. Users get immediate, smooth resistance and proper muscle loading through the complete range of motion, leading to unprecedented results.

LEG EXTENSION

The Nautilus Nitro® EVO Leg Extension positions the body to allow maximum range knee extension while maintaining axis alignment.

- Reclined seat back angle prevents hamstrings from interfering with full range quadriceps contraction
- Quick-set leg pad for proper positioning of all users
- Heavy padded movement arm roller for user comfort
- Improved cam profile allows full contraction in extended position
- 55" L x 36" W x 54" H / 140 L x 91 W x 137 H cm
- Machine Weight: 557 lbs. / 253 kg, Weight Stack: 245 lbs. / 113 kg