

EVO OVERHEAD PRESS

ITEM # S90P



FOR YOUR PROTECTION,
THIS EQUIPMENT HAS
BEEN TREATED WITH
mPale™ ANTIMICROBIAL.

www.mpactusa.com

Updated Look. Improved Function.

Nautilus Nitro® EVO features our patent pending 5 lb Increment weight stack, which is perfect for slight strength gains and ideal for newcomers, women and the elderly. Other features include:

- Updated Sleek, Partially Enclosed Weight Shields with a 5.5" Opening
- Marine Grade, Contoured Upholstery for Comfort & Durability
- Updated Exercise Placards for Ease of Use
- Integrated Parts Schematic Simplifies Service
- Proprietary Pin Design Limits Pilferage & Misuse Liability
- Enlarged Bottle Holder & Towel Knob for Convenience
- Multiple Color Options are Available for the Frame and Upholstery
- Warranty: 12 years- Frame/Welded Moving Parts/Weight Stacks, 3 years-Moving Parts, 1 year-Labor and 6 months on upholstery/pads/grips and tethered weight stack pins

It Moves the Way Your Body Moves. Driven by our four-bar linkage system, cam design or a combination of both, this unique technology dynamically matches the body's potential increases and decreases in strength. Users get immediate, smooth resistance and proper muscle loading through the complete range of motion, leading to unprecedented results.

OVERHEAD PRESS

The Nautilus Nitro® EVO Overhead Press provides an easy- entry start position without compromising the user's full range of motion.

- Converging, dependent movement arms provide equal loading and greater range of movement
- Function Generator four-bar linkage drive system to generate correct strength profile
- Multiple position oversized handles distribute load over greater area of hands for increased comfort and user preference
- 57" L x 41" W x 58" H / 145 L x 104 W x 147 H cm
- Machine Weight: 482 lbs. / 219 kg, Weight Stack: 245 lbs. /113 kg