

**EVO REAR DELT / PEC FLY**

ITEM # S9RDPF



OPTIONAL FOOT REST

Item # 95-0570

FOR YOUR PROTECTION,  
THIS EQUIPMENT HAS  
BEEN TREATED WITH  
mPale™ ANTIMICROBIAL.[www.mpactusa.com](http://www.mpactusa.com)**Updated Look. Improved Function.**

Nautilus Nitro® EVO features our patent pending 5 lb Increment weight stack, which is perfect for slight strength gains and ideal for newcomers, women and the elderly. Other features include:

- Updated Sleek, Partially Enclosed Weight Shields with a 5.5" Opening
- Marine Grade, Contoured Upholstery for Comfort & Durability
- Updated Exercise Placards for Ease of Use
- Integrated Parts Schematic Simplifies Service
- Proprietary Pin Design Limits Pilferage & Misuse Liability
- Enlarged Bottle Holder & Towel Knob for Convenience
- Multiple Color Options are Available for the Frame and Upholstery
- Warranty: 12 years- Frame/Welded Moving Parts/Weight Stacks, 3 years-Moving Parts, 1 year-Labor and 6 months on upholstery/pads/grips and tethered weight stack pins

**It Moves the Way Your Body Moves.** Driven by our four-bar linkage system, cam design or a combination of both, this unique technology dynamically matches the body's potential increases and decreases in strength. Users get immediate, smooth resistance and proper muscle loading through the complete range of motion, leading to unprecedented results.

**REAR DELT / PEC FLY**

The Nautilus Nitro® EVO Rear Delt/Pec Fly offers two distinct and direct rotary movements for the muscles of the chest, shoulders and upper back.

- Dependent mechanism synchronizes movement arms and provides more stable movement
- Single, overhead adjustment allows fast, easy selection of both movement arms simultaneously, without user position change
- Machine design allows user to remain seated during transition from one exercise to another
- Optimum "range of possible rotary movement" by innovative design
- 67" L x 35" W x 73" H / 170 L x 89 W x 185 H cm
- Machine Weight: 535 lbs. / 243 kg, Weight Stack: 200 lbs. / 91 kg