

EVO SUPER PULLOVER

ITEM # S9SP



FOR YOUR PROTECTION,
THIS EQUIPMENT HAS
BEEN TREATED WITH
mPale™ ANTIMICROBIAL.

www.mpactusa.com

Updated Look. Improved Function.

Nautilus Nitro® EVO features our patent pending 5 lb Increment weight stack, which is perfect for slight strength gains and ideal for newcomers, women and the elderly. Other features include:

- Updated Sleek, Partially Enclosed Weight Shields with a 5.5" Opening
- Marine Grade, Contoured Upholstery for Comfort & Durability
- Updated Exercise Placards for Ease of Use
- Integrated Parts Schematic Simplifies Service
- Proprietary Pin Design Limits Pilferage & Misuse Liability
- Enlarged Bottle Holder & Towel Knob for Convenience
- Multiple Color Options are Available for the Frame and Upholstery
- Warranty: 12 years- Frame/Welded Moving Parts/Weight Stacks, 3 years-Moving Parts, 1 year-Labor and 6 months on upholstery/pads/grips and tethered weight stack pins

It Moves the Way Your Body Moves. Driven by our four-bar linkage system, cam design or a combination of both, this unique technology dynamically matches the body's potential increases and decreases in strength. Users get immediate, smooth resistance and proper muscle loading through the complete range of motion, leading to unprecedented results.

SUPER PULLOVER

The Nautilus Nitro® EVO Super Pullover is praised as the 'upper body' squat machine that delivers the most important, full-range movement for the latissimus dorsi and other torso muscles.

- 250 degrees of shoulder rotation
- Contoured back pad for unrestricted movement in starting position
- Angled movement arm pads for comfort and accommodation of various user sizes
- Tiered foot pedal for easy entry and exit
- Ergonomically designed movement arm accommodates all users
- 57" L x 46" W x 67" H / 145 L x 117 W x 170 H cm
- Machine Weight: 638 lbs. / 289 kg, Weight Stack: 245 lbs. / 113 kg