

TRUE[®] C O M M E R C I A L

CS800 TREADMILL



The TRUE CS800 is built on a commercial 11-gauge, robotically welded steel frame that provides uncompromising stability even under the most rigorous pounding. Despite its brawny construction, the smooth, sweeping hydroformed steel pedestals, brushed aluminum powder coat finish and matched aluminum straddle covers provide a sleek, contoured presentation that is a dramatic accent to any fitness environment.

PREMIUM FEATURES:

- **POWERFUL DRIVE SYSTEM:** Equipped with a 5hp Max-Drive motor featuring an internal self-cooling system ensuring years of powerful and dependable operation.
- **TRUE HRC (HEART RATE CONTROL)[®]:** Includes one touch HRC Cruise Control™ which allows the user to “lock in” on a specific target heart rate.
- **TRUE IMPACT ABSORPTION:** TRUE’s patented Soft System™ offers the most orthopedically correct running surface available.
- **BUILT FOR THE LONG RUN:** Tested for thousands of hours on TRUE’s “Treadbuster” and backed accordingly.
- **USER FRIENDLY EXPERIENCE:** Mid-bar control switches put the power literally at your users’ fingertips.
- **UNSURPASSED WARRANTY:** Includes deck and belt.



15" Touch Screen w/Advanced iPod[®]:

- Integrated 15" LCD with Touch Screen technology
- Advanced iPod[®] compatibility allows user to easily watch TV, listen to their personal playlist, while simultaneously monitoring their workout performance
- Scenic landscape perspectives allow users to escape into hundreds of alternating serene views
- Goal-focused interface allows users to easily find numerous workout options
- Easy to use language options at the touch of a button
- 21 Preset programs, 4 Custom Programs*, 5 Saved Workouts



11" Custom LCD w/Basic iPod[®]:

- Intuitive 11" Custom LCD display provides pertinent information to users in an easy-to-read presentation
- Optional wireless entertainment control
- Basic iPod[®] compatibility allows users to dock, charge, and change songs
- 14 Preset programs, 3 Custom Programs

TRUE[®] C O M M E R C I A L

CS800 TREADMILL

DRIVE SYSTEM	Drive Motor	TRUE 5hp AC Max Drive™		
	Incline Motor	Compression Elevation Motor with 1000 lbs of Thrust		
	Speed Sensor	Optical		
	Power Source	120 Volt/20 Amp Dedicated (NEMA 5-20 Receptacle) Cord Length 12' (3.7m) - 220v Option Available		
EXERCISE SURFACE	Deck	Double Sided Thermally Fused Laminated 1" Medium Density Fiberboard		
	Reversible Deck	YES		
	Belt	Siegling Multi-Ply Belt with PVC Coating		
	Rollers	3.5" Diameter Rollers with Sealed Bearings		
	Impact System	TRUE Soft System™ (neoprene shock absorbers)		
	Lubrication	TRUE Proprietary Lubricant "Silax"®		
FRAME	Frame	11-Gauge Heavy-Duty Welded Steel		
	Pedestals	Hydroformed Steel		
	Handrails	Molded Urethane, Moisture Resistant Flared Handrails		
	Medical Handrails	YES		
CONSOLE	Display Type	15" Touch Screen: CS800-T15T	11" Custom LCD: CS800-T11	
	iPod® Compatibility	Advanced	Basic	
	Entertainment Capabilities	Integrated 15" LCD with Touch Screen technology and built-in TV, integrated iPod® connectivity with music and video featuring onscreen navigation, Scenic Landscape Perspectives, USB connectivity, NTSC/ATSC/QAM digital tuner or PAL/SECAM tuner	Optional integrated wireless entertainment control, integrated iPod® connector	
	Communications	Full CSAFE Compatibility - Fitlinxx*		
	Key Type	Membrane - Center Pod Only	Membrane	
	Command Keys	1 Touch Quick Speed, HRC Cruise Control®	1 Touch Quick Speed, HRC Cruise Control®	
	Data Readouts	Speed, Incline, Elapsed Time, Time Remaining, Distance, Distance Remaining, Pace, Heart Rate, Target Heart Rate, METs, Calories, Calories/Hour, Segment Time Remaining	Speed, Incline, Elapsed Time, Time Remaining, Distance, Pace, Heart Rate, Target Heart Rate, % of Maximum Heart Rate, METs, Calories, Level	
	Diagnostics	YES		
HEART RATE	Contact Heart Rate Monitoring	YES		
	Wireless Heart Rate Monitoring	Wireless - Polar® Equipped		
	HRC (Heart Rate Control)® Workouts	YES - 8	YES - 1	
	HRC Cruise Control™	YES		
PROGRAMMING	Workouts	14 Preset, 3 Custom	14 Preset, 3 Custom	
	Fitness Tests	Gerkin Protocol and 4-Military	Gerkin Protocol and 4-Military	
OTHER FEATURES	Accessories	Reading Rack, 2 Water Bottle Holders, 2 Accessory Trays		
	Safety	Safety Clip Equipped, Extended Handrails, Large Straddle Covers, User Present Detection™		
	Balance Bar Control Pad	YES		
	Personal Cooling System	YES		
PHYSICAL SPECIFICATIONS	Footprint	84.5"L x 37"W (215 cm x 94 cm)		
	Running Surface	63"L x 23"W (160 cm x 58 cm)		
	Machine Weight / Shipping Weight	511 lbs (234 kg) / 616 lbs (280 kg)	511 lbs (232 kg) / 609 lbs (277 kg)	
	Maximum User Weight	500 lbs (227 kg)		
	Decline Option	YES		
	Incline Range	0 to 18% standard; with decline -3 to 18%		
	Speed Range	0.5 -12 mph (0-19 kph); with decline 0-15 mph (0-24 kph)		
	Step-Up Height	11.5" (29 cm); with decline 13.5" (35 cm)		
	Portability	Front Transport Wheels with Built in Rear Handholds		
	Regulatory Approvals	ETL, FCC, CSA (CE for 220 v)		
	WARRANTY	Warranty	Commercial - Frame Life, Motor 5 Yrs, Parts 3 Yrs, Labor 3 Yrs, Touch Screen Console 3 Yrs, Headphone jack, iPod® Connector, and USB port - 90 days parts, no labor	Commercial - Frame Life, Motor 5 Yrs, Parts 3 Yrs, Labor 3 Yrs, Headphone jack, iPod® Connector, and USB port - 90 days parts, no labor

* In development, please ask Sales Rep for availability. Specifications subject to change without notice