

**F3 ADJUSTABLE TOWER PULLEY
SYSTEM - DUAL STACK**

ITEM # F3ATM-2



FOR YOUR PROTECTION,
THIS EQUIPMENT HAS
BEEN TREATED WITH
mPale™ ANTIMICROBIAL.

www.mpactusa.com

VERSATILITY. Nautilus® pulley systems offer you an infinite number of possibilities. From physical therapy to sports-specific applications and general exercise use, you'll find the highest performance line of commercial pulley systems that we've ever developed.

INDUSTRIAL-GRADE. The Nautilus® Commercial F3 line uses 11-gauge steel frame tubes to incorporate a new, softer curved profile for a strong, modern look. Pivot points use durable bronze bushings. Multiple color options are available for the frame.

- Compact design allows over 40 exercises from a standing, lying or seated position using optional handle package (95-0590)
- Dual weight stack allows two individuals to exercise at the same time
- Dual pulleys on each weight stack have 21 indexed vertical height adjustments and allow a choice of unilateral or bilateral exercise
- Two 250 lb weight stacks in 10 lb increments.
- With a 2:1 lifting ratio, the effective incremental resistance increase at one handle is only 5 lbs.
- Wheelchair accessible
- 34" L x 68" W x 92" H/ 86 L x 172 W x 233 H cm
- Warranty: 85 WbSfeS Vi VW Wfe >XVW W ? WZS [US^bSfe,%kVSc- I VScbSfe, (_ a` fZe - >STad #kVScd />STadi SdS fk Sbb^Va` k fa GE3 S V 5S SVSž 8adUa_b^VWVWS[ea` kagd^_ [fVW i SdS fkl b^VSe^VWV? WZž[f EkefW_ ey>_ [fVW I SdS fka` agdi WefVWSf i i i ž Sgf[gdla_ _ VUJSZLa_ ži